

1. Access to Damage Code (DC)

Damage Code can be called up from the XENTRY Truck directly. **1** Alternatively, call up DC via XENTRY Operation Time or XENTRY TIS. Here, you have the option of determining the damage code for an operation number and saving it in the order.




Note: All passenger car screenshots shown in this document also apply to trucks.

2. Defining a vehicle

Upon accessing this menu, you have two options to define the vehicle:

- 1** Enter a FIN/VIN and click on the magnifying glass.
- 2** Selecting via mode and vehicle type


Once you have defined the vehicle, the “OK” icon becomes active and you can confirm your selection by clicking on it. **3**



3. Selecting an image


You have two options for selecting the correct image.

- 1** To do this, open the function groups and make a selection.
- 2** Alternatively, you can enter the fault location into the input field directly and start the search. Only function groups that contain the fault location that has been entered are displayed.
- 3** Make a selection and activate the correct image by clicking on it.




4. Determining a fault location

Now you can select the fault location. To do this, click on the corresponding part in the image, **1** or select the fault location on the left in the drop-down list. **2**



5. Determining a fault type

Define the fault type, the options for which are displayed based on the fault location.



6. Determining a warranty type

Define the warranty type. There are two options here, which are the same for each vehicle.

